

Penn Reel Parts list for:

Model: 20T

| KEY NO | PART NO. | DESCRIPTION | KEY NO | PART NO. | DESCRIPTION |
|--------|----------|-------------------------------|--------|----------|----------------------------------|
| 1 | 1-20TN | RIGHT SIDE PLATE ASSEMBLY | 54 | 54-30T | HARNESS LUG (2 REQ.) |
| 2 | 2-30 | QUADRANT RING | 55 | 55-80 | LEFT-SIDE BEARING |
| 4 | 4-30 | CAM THRUST WASHER | 59 | 59-50 | SLOTTED WASHER |
| 5 | 5-50 | MAIN GEAR HIGH SPEED | 60 | 60-50 | BACKING WASHER |
| 6 | 6-155 | PRESET SPACER WASHER | 62 | 62-50 | CLICK SPRING |
| 7 | 7-30 | METAL DRAG WASHER | 63 | 63-30T | STAND SCREW (4 REQ.) |
| 9 | 9-30 | SPACING SLEEVE | 69 | 69-50 | LOCATING PIN (2 REQ.) |
| 13 | 13-20 | PINION GEAR | 69B | 69B-50 | RETAINING RING (2 REQ.) |
| 14 | 14-50 | DOG SPRING (2 REQ.) | 81 | 81-50 | RATCHET |
| 15 | 15-50 | DOG (2 REQ.) | 95 | 95-50 | CLICK TONGUE BUSHING |
| 18 | 18-30 | DISC CLUTCH SPRING (4 REQ.) | 95A | 95A-20 | CLICK BUSHING WASHER |
| 19 | 19-20 | ECCENTRIC CAM | 95C | 95A-50 | CLICK BUSHING WASHER |
| 20 | 20L-704 | BALL BEARING (3 REQ.) | 98 | 98-30TN | BRIDGE BUSHING |
| 21 | 21-30 | ECCENTRIC LEVER | 101 | 101-30 | DRIVE PLATE SCREW (8 REQ.) |
| 22 | 22-109 | DOG SPRING SCREW (2 REQ.) | 110 | 110-50 | HANDLE LOCK SCREW |
| 23 | 23-114 | HANDLE SCREW | 110A | 110A-50 | HANDLE LOCKING PLATE |
| 24 | 24-30TW | HANDLE COMPLETE | 112 | 112-50 | ECCENTRIC LEVER KNOB |
| 27 | 27-20T | L.S. PLATE ASSEMBLY | 112A | 112A-50 | ECCENTRIC KNOB SCREW |
| 29L | 29L-20 | SPOOL | 113 | 113-50 | ECCENTRIC LEVER CAP |
| 30 | 30-20T | STAND | 117 | 117DN-30 | DRIVE PLATE W/ DRAG WASHER |
| 31 | 31T-20 | SHORT QUADRANT SCREW | 119 | 119-50 | COUPLING PLATE |
| 31A | 31T-80 | FRAME SCREW (7 REQ.) | 124 | 124-30 | BRIDGE COVER |
| 32 | 32-14CH | CENTER QUADRANT SCREW | | *125-30 | CAM HOUSING |
| 33 | 33-49 | ROD CLAMP | 124 | 124-30 | BRIDGE COVER |
| 33C | 33C-20T | ROD CLAMP KIT INC WRENCH | 134 | 134-50 | GEAR STUD |
| 34 | 34-30T | ROD CLAMP SCREW (2 REQ.) | 134A | 134A-50 | GEAR STUD WASHER |
| 34C | 34C-30T | ROD CLAMP SCREW (2 REQ.) | 141 | 141-30 | CAM FOLLOWER |
| 35 | 35-50N | CLICK TONGUE | 142 | 142-50 | CAM FOLLOWER PIN (2 REQ.) |
| 36 | 36-50 | CLICK BUTTON | 1 | 43143-30 | ADJUSTING SCREW |
| 36A | 36-700 | CLICK BUTTON NUT | 144 | 144-50 | PRESET KNOB |
| 36S | 36S-80ST | CLICK BUTTON CAP | 152A | 152A-30T | ROD CLAMP ACORN NUT (2 REQ) |
| 38 | 38-7 | COUPLING PLATE SCREW (3 REQ.) | 156 | 156-30 | DRAG COVER |
| 38A | 38-50 | FRAME SCREW (2 REQ.) | 157 | 157-50 | QUADRANT SPACER BUSHING (2 REQ.) |
| 38B | 38T-80 | LONG QUADRANT SCREW | 161 | 161-50 | LOCATING PIN BUSHING (2 REQ.) |
| 38C | 38-710 | CLICK BUSHING NUT | 162 | 162-50 | LOCATING PIN SPRING (2 REQ.) |
| 39A | 39A-80S | BRIDGE COVER SCREW (3 REQ.) | 183 | 183-20T | TUBE FRAME |
| 41 | 41-50 | L.S. BEARING SPRING | 264 | 264-30T | STAND GASKET |

*** Not Shown**

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.
SBT Ver. 080312