





Thank you for your recent PENN gear purchase. No matter where you fish or what you fish for, you can depend PENN to perform in any battle day in and day out. Now it's time to get your product registered and get out on the water.

<https://register.pennfishing.com>

KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION	KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION	KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
1	1632265	1-BTLIV8000	Housing Assembly	27	1632267	27-BTLIV8000	Rotor	47	1632272	47-BTLIV8000	Spool Assembly
1E	1529526	1E-BTLIII8000	Housing Slope	27A	1632268	27A-BTLIV8000	Bail Pivot Cover	48	1211625	48-5000SG	Click Tongue
4	1190939	4-7000SG	A/R Dog	28	1529536	28-BTLIII8000	Trip Lever	48A	1211626	48A-5000SG	Click Tongue Washer
5	1190966	5-5000SG	Dog Spring	31	1365758	31-FRCII8000	Bail Arm Screw (2 req)	48B	1489327	48B-SSVI7500	Spool Click Screw
6	1190979	6-5000SG	Retaining Clip	32	1313874	32-CFT8000	Bail Spring	49	1211627	49-5000SG	Click Tongue Spring
8	1529527	8-BTLIII8000	Main Gear	34	1313875	34-CFT8000	Bail Arm	51	1308112	51-CFT5000	Drag Retaining Ring
8A	1191031	8A-7000SG	Shim	34C	1529537	34C-BTLIII8000	Pivot Arm	52	1632273	52-BTLIV8000	Drag Knob Assembly
10	1313864	10-CFT8000	A/R Holder	35	1529538	35-BTLIII8000	Line Roller	56	1313883	56-CFT8000	Drag Washer (3 req)
11	1529528	11-BTLIII8000	Bushing	35A	1242222	35A-5000BTL	Bearing	57	1211646	57-7000BTL	Keyed Washer (3 req)
12	1313865	12-CFT8000	A/R Bushing Spring	36	1191699	36-3000SG	Stud Screw	60	1489320	39A-SSVI7500	Thrust Washer
15	1632266	15-BTLIV8000	Handle Assembly	38	1632269	38-BTLIV8000	Rotor Nut	95B	1308115	95B-CFT5000	Rotor Locking Plate
19	1529530	19-BTLIII8000	Pinion Gear	38A	1204016	21A-5000PUR	Screw	98C	1489332	98C-SSVI7500	Clutch/Sleeve Assembly
19A	1489299	19A-SSVI7500	BUSHING	38F	1632270	38F-BTLIV8000	Main Shaft Seal Ring	132	1529545	132-BTLIII8000	Roller Washer
20	1489300	20-SSVI7500	Ball Bearing (4 req)	39	1529540	39-BTLIII8000	Main Shaft Assembly	132A	1489334	132A-SSVI7500	Line Roller Washer
21	1192636	21-5000SG	Bearing Retainer	43	1529541	43-BTLIII8000	Crosswind Block	226	1632274	226-BTLIV8000	Rear Cover
21A	1192645	21A-5000SG	Bearing Retainer Screw (3 req)	43A	1489323	43A-SSVI7500	Crosswind Block Plate	226A	1529386	226A-BTLIII3000	Rear Cover Screw
21B	1529531	21B-BTLIII8000	Collar	43B	1489213	43B-SSVI3500	Plate Screw (3 req)	231	1529547	231-BTLIII8000	Crosswind Gear
22	1204018	22-6000PUR	Screw	44	1191845	44-5000SG	Crosswind Block Screw (2 req)	231B	1489338	231B-SSVI7500	Screw Crosswind Gear
24	1529532	24-BTLIII8000	Bail Wire Assembly	45	1632271	45-BTLIV8000	Housing Cover	233	1632245	233-BTLIV5000	Bearing Cover Assembly
25	1529533	25-BTLIII8000	Bail Holder	46	1191903	46-5000SG	Housing Cover Screw (4 req)				