

Penn Reel Parts list for:

Model: 2000CQ (also known as CQR2000) Conquer

| KEY NO | PART NO. | DESCRIPTION | KEY NO | PART NO. | DESCRIPTION |
|--------|------------|------------------------------|--------|-------------|--------------------------------|
| 1 | 1-2000CQ | HOUSING | 46A | 46A-2000CQ | SCREW |
| 1A | 1A-2000CQ | HOUSING PLATE | 46S | 46S-2000CQ | SPRING |
| 8 | 8-2000CQ | MAIN GEAR | 47 | 47-2000CQ | SPOOL ASSEMBLY |
| 8A | 8A-2000CQ | SHIM | 47P | 47P-2000CQ | SPOOL (ONLY) |
| 15 | 15-2000CQ | HANDLE ASSEMBLY | 47B | 47B-4000CQ | SPOOL BAND |
| 19 | 19-2000CQ | PINION | 47C | 47C-2000CQ | SPOOL LIP COVER |
| 20 | 20-4200 | BALL BEARING (USES 4) | 47D | 47D-2000CQ | LINE CLIP |
| 21 | 21-2000CQ | BEARING RETAINER | 47E | 47E-2000CQ | LINE CLIP SPRING |
| 21A | 21A-2000CQ | SCREW (USES 3) | 47L | 47L-2000CQ | SPOOL LIP |
| 21B | 21B-2000CQ | COLLAR | 48 | 48-2000CQ | SPOOL CLICK |
| 22 | 22-2000CQ | SCREW (USES 2) | 48A | 48A-2000CQ | SPOOL CLICK RETAINER |
| 24 | 24-2000CQ | BAIL WIRE | 48B | 48B-2000CQ | SPOOL CLICK HOUSING |
| 25 | 25-2000CQ | BAIL CAM | 48D | 48D-2000CQ | SPACER RING |
| 25A | 25A-2000CQ | O-RING | 48E | 48E-2000CQ | O-RING |
| 25B | 25B-2000CQ | CLIP | 51A | 51A-2000CQ | SCREW (12 REQUIRED) |
| 27 | 27-2000CQ | ROTOR | 52 | 52-2000CQ | DRAG KNOB ASSEMBLY |
| 27A | 27A-2000CQ | BAIL PIVOT COVER | 56 | 56-2000CQ | DRAG WASER HT-100 (2 REQUIRED) |
| 28 | 28-2000CQ | TRIP LEVER | 57 | 57-2000CQ | KEYED WASHER (2 REQUIRED) |
| 28D | 28D-4000CQ | FRICTION RING | 58 | 58-4000CQ | EARRED WASHER |
| 28E | 28E-4000CQ | FRICTION RING COVER | 58A | 58A-2000CQ | EARRED WASHER |
| 28S | 28S-2000CQ | FRICTION RING SCREW (USES 3) | 60 | 60-2000CQ | SPACER WASHER |
| 31 | 31-2000CQ | SCREW (USES 2) | 60A | 60A-2000CQ | O-RING |
| 32 | 32-2000CQ | BAIL SPRING | 60B | 60B-2000CQ | BALL BEARING |
| 34 | 34-2000CQ | BAIL ARM | 60C | 60C-2000CQ | BEARING SLEEVE |
| 34B | 34B-2000CQ | PIVOT LEVER | 60S | 60S-2000CQ | SEAL |
| 34C | 34C-2000CQ | PIVOT ARM | 60W | 60W-2000CQ | SPOOL SHAFT WASHER |
| 35 | 35-2000CQ | LINE ROLLER | 64 | 64-2000CQ | IDLER GEAR |
| 35A | 35A-2000CQ | BALL BEARING (USES 4) | 95B | 95B-2000CQ | ROTOR LOCKING PLATE |
| 36 | 36-2000CQ | SCREW, LINE ROLLER | 97 | 97-2000CQ | CLUTCH SPRING |
| 38 | 38-2000CQ | ROTOR NUT | 98C | 98C-2000CQ | CLUTCH/SLEEVE ASSEMBLY |
| 38A | 38A-2000CQ | SCREW, ROTOR LOCKING PLATE | 132A | 132A-2000CQ | SPACER (2 REQUIRED) |
| 39 | 39-2000CQ | SPOOL SHAFT | 226 | 226-2000CQ | REAR COVER |
| 43 | 43-2000CQ | CROSSWIND BLOCK | 227 | 227-2000CQ | CAM COVER |
| 43A | 43A-2000CQ | CROSSWIND BLOCK PIN | 231 | 231-2000CQ | CROSSWIND GEAR |
| 44 | 44-2000CQ | SCREW, CROSSWIND BLOCK | 231B | 231B-2000CQ | CROSSWIND GEAR SCREW |
| 45 | 45-2000CQ | MAINTENANCE HATCH | 232 | 232-2000CQ | BEARING RETAINER (2 REQUIRED) |
| 46 | 46-2000CQ | SCREW | 233 | 233-2000CQ | BEARING COVER |

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.
SBT Ver. 020410

It is likely that Penn will only sell the 47-2000CQ spool assembly rather than the 47P bare spool.