




PARTS LIST FOR MODEL AS PASII5000



KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
1	1558015	1-PASII5000	Housing Assembly
4	1190937	4-5000SG	Dog
5	1190966	5-5000SG	Dog Spring
6	1190979	6-5000SG	Retaining Clip
8	1204009	8-5000PUR	Main Gear
8A	1191030	8A-5000SG	Shim
10	1191066	10-5000SG	A/R Holder
11	1191085	11-5000SG	Bushing
12	1313865	12-CFT8000	A/R Bushing Spring
15	1558016	15-PASII5000	Handle Assembly
19	1450273	19-PAS5000	Pinion Gear
19A	1191253	19A-5000SG	Pinion Bushing
20	1308090	20-CFT5000	Ball Bearing (3 req)
20A	1308090	20-CFT5000	Upper Pinion Ball Bearing
21	1192636	21-5000SG	Bearing Retainer

KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
21A	1192645	21A-5000SG	Bearing Retainer Screw (3 req)
21B	1324209	21B-BTLII5000	Collar
22	1204018	22-6000PUR	Bail Pivot Cover Screw
24	1558017	24-PASII5000	Bail Wire
25	1308093	25-CFT5000	Bail Holder
27	1524123	27-FRCII5000	Rotor
27A	1365738	27A-FRCII5000	Bail Pivot Cover
28	1365739	28-FRCII5000	Trip Lever
31	1365740	31-FRCII5000	Bail Arm Screw (2 req)
32	1308101	32-CFT5000	Bail Spring
34	1308102	34-CFT5000	Bail Arm
34C	1191652	34C-5000SG	Pivot Arm
35	1489400	35-SSVI5500	Line Roller
35A	1489411	132A-SSVI5500	Line Roller Bushing
36	1191699	36-3000SG	Bail Stud Screw
38	1191729	38-5000SG	Rotor Nut
38A	1365741	38A-FRCII5000	Screw
38D	1308104	38D-CFT5000	Rotor Nut Washer
39	1308105	39-CFT5000	Main Shaft Assembly
43	1308107	43-CFT5000	Crosswind Block
43A	1191820	43A-5000SG	Crosswind Block Plate
43B	1191736	38A-5000SG	Crosswind Block Plate Screw(2 req)
44	1191845	44-5000SG	Crosswind Block Screw (2 req)
45	1558018	45-PASII5000	Housing Cover Assy
46	1191903	46-5000SG	Housing Cover Screw (3 req)
46B	1191908	46B-5000SG	Housing Cover Washer (3 req)
47	1558019	47-PASII5000	Spool Assembly
48	1211625	48-5000SG	Click Tongue
48A	1211626	48A-5000SG	Click Tongue Washer
48B	1192658	22-2000SG	Bail Pivot Cover Screw
49	1211627	49-5000SG	Click Tongue Spring
51	1308112	51-CFT5000	Drag Retaining Ring
52	1514319	52-FRCII5000	Drag Knob Assembly
56	1308114	56-CFT5000	Drag Washer (3 req)
57	1192044	57-5000SG	Keyed Washer (3 req)
60	1211629	60-5000BTL	Thrust Washer
95B	1308115	95B-CFT5000	Rotor Locking Plate
98C	1308116	98C-CFT5000	Clutch/Sleeve Assembly
132	1558020	132-PASII5000	Roller Bushing
132A	1242222	35A-5000BTL	Line Roller Bearing
226	1308117	226-CFT5000	Rear Cover
226A	1192473	226A-3000SG	Rear Cover Screw
231	1192503	231-5000SG	Crosswind Gear
233	1529496	233-BTLIII5000	Bearing Cover Assembly