

PARTS LIST FOR MODEL: WAR30LW Warfare Level Wind Reel

27A ** SEE NOTES PAGE 3

						D. C. C. D. I. D. L.	
<u>KEY</u> #	PUREFISHING #	PENN PARI #	DESCRIPTION	<u>KEY</u> #	PUREFISHING #	PENN PARI #	DESCRIPTION
1	1383101	1-WAR30LW	HANDLE SIDE PLATE ASSEMBLY	27B	1383028	27B-WAR15LW	SCREW (2 REQUIRED)
2	1383102	2-WAR30LW	RING, HANDLE SIDE	27C	1383029	27C-WAR15LW	SCREW
3	1384179	3-WA <mark>R1</mark> 5LW	BRIDGE	28	1383285	28-WAR30LW	RING, NON HANDLE SIDE
4	1382976	4-WA <mark>R15LW</mark>	DRAG WASHER, HT100	29A **	SEE NOTES PAGE	3	
5	1383103	5-WAR30LW	MAIN GEAR	29	1383286	29-WAR30LW	SPOOL
6	1382978	6-WAR15LW	DRAG WASHER, HT100, EARRED (2 REQUIRED)	29L	1383287	29L-WAR30LW	SPOOL ASSEMBLY
7	1382999	7-WAR15LW	KEYED METAL DRAG WASHER	33	1182754	33N-113	CLAMP, GRAPHITE WITH RING
7H	1383000	7H-WAR15LW	HEAVY METAL DRAG WASHER	33C	1182773	33C-113	CLAMP KIT WITH STUDS AND NUTS
8	1383001	8-WAR15LW	SPRI <mark>NG WASH</mark> ER (4 <mark>REQ</mark> UIRED)	34	1182788	34-45	STUD (2 REQUIRED)
9	1384180	9-WAR15LW	SPACING SLEEVE	34C	1182862	34C-45	STUD WITH TWO NUTS (2 REQUIRED)
10	1383002	10-WAR15LW	STAR DRAG	35	1383037	35-WAR15LW	CLICK TONGUE
10A	1383003	10A-WAR15LW	STAR CLICK RETAINER	36	1383038	36-WAR15LW	CLICK BUTTON
10B	1383004	10B-WAR15LW	STAR CLICK WASHER	38	1383039	38-WAR15LW	SCREW (8 REQUIRED)
10C	1383005	10C-WAR15LW	STAR CLICK SPRING	40 ** S	EE NOTES PAGE 3	}	
11	1383104	11-WAR30LW	ECCENTRIC JACK	40A **	SEE NOTES PAGE	3	
12	1383007	12-WAR15LW	PINION YOKE	40B*	1383044	40B-WAR15LW	PLASTIC WASHER*
13	1383105	13-WAR30LW	PINION	40C	1383045	40C-WAR15LW	WASHER, ACETAL THRUST
15	1383009	15-WAR15LW	ANTI-REVERSE DOG (2 REQUIRED)	40D	1383046	40D-WAR15LW	WASHER, RUBBER THRUST
16	1383010	16-WAR15LW	SCREW, FOR BRIDGE (2 REQUIRED)	40E	1383047	40E-WAR15LW	THRUSH WASHER (2-3 REQUIRED)
18	1383011	18-WAR15LW	PINION YOKE SPRING (2 REQUIRED)	41A	1384181	41A-WAR15LW	BUSHING
19	1383012	19-WAR15LW	ECCENTRIC	42	1383318	42-WAR30LW	WORM SHAFT ASSEMBLY
20	1383013	20-WAR15LW	ECCENTRIC SPRING	43	1383051	43-WAR15LW	WORM SHAFT BUSHING (2 REQUIRED)
21	1383106	21-WAR30LW	ECCENTRIC LEVER	46	1383288	46-WAR30LW	LINE GUIDE ASSEMBLY
22	1383015	22-WAR15LW	ECCENTRIC SCREW	47	1383053	47-WAR15LW	LINE GUIDE PAWL
23	1383016	23-WAR15LW	HANDLE ASSEMBLY SCREW	47A	1383054	47A-WAR15LW	PAWL SHIM
23A	1383017	23A-WAR15LW	HANDLE LOCK SCREW	48	1383055	48-WAR15LW	L <mark>IN</mark> E GUIDE NUT
23B	1383018	23B-WAR15LW	HANDLE SCREW WASHER	50	1383057	50-WAR20LW	WORM SHIELD
24	1383019	24-WAR15LW	HANDLE ASSEMBLY	55 ** S	EE NOTES PAGE 3	}	
24A	1383020	24A-WAR15LW	HANDLE THRUST WASHER	58	1383059	58-WAR20LW	LINE GUID <mark>E P</mark> OST
26	1383021	26-WAR15LW	SPOOL TENSION CONTROL CAP	60	1383060	60-WAR15LW	WORM SHAFT WASHER (2 REQUIRED)
26A	1383022	26A-WAR15LW	BUSHING (2 REQUIRED) (AKA old# 41-WAR15LW)	62*	1383061	62-WAR15LW	SPRING
26B	1383023	26B-WAR15LW	CLUTCH RETAINER	64	1383289	64-WAR30LW	IDLER GEAR
26C	1383024	26C-WAR15LW	SCREW, FOR CLUTCH RETAINER (2 REQUIRED)				
27	1383284	27-WAR30LW	NON-HANDLE SIDE PLATE				

PAGE 2 OF 3

(cont'd)

KEY #	PUREFISHING #	<u>PENN</u> PART #	DESCRIPTION	<u>KEY</u> #	PUREFISHING #	PENN PART #	DESCRIPTION
66	1383290	66-WAR30LW	CLICK RATCHET	985	1383070	98S-WAR15LW	CLUTCH SLEEVE
66A	1383064	66A-WAR15LW	SPOOL GEAR	120	1383071	120-WAR15LW	O-RING
69	1383065	69-WAR15LW	RETAINER RING	134A	1383072	134A-WAR15LW	CLUTCH RECOVER PLATE
69A	1383066	69A-WAR15LW	RETAINER RING (2 REQUIRED)	134B	1383073	134B-WAR15LW	CLUTCH RECOVER SUPPORT PLATE
98	1383067	98-WAR15LW	MAIN GEAR SHAFT	134C	1383074	134C-WAR15LW	CLUTCH RECOVER SPRING
98A	1383068	98A-WAR15LW	CLUTCH HOUSING	149	1184702	1 <mark>49-45</mark>	ROD CLAMP NUT (2 REQUIRED)
98B	1384182	98B-WAR15LW	CLUTCH (SHARP EDGE FACES TOWARDS SPOOL)	149A	1184706	149-200	HEX NUT (2 REQUIRED)
98R	1383069	98R-WAR15LW	ANTI REVERSE RATCHET	154*	1383077	154-WAR15LW	CLICK BUTTON WASHER
				158	1383078	158-WAR15LW	DOG PIN (2 REQUIRED)
				183	1383078	183-WAR30LW	FRAME ASSEMBLY

ERRORS/CORRECTIONS/NOTES:

^{*154} This washer shows on the schematic, but was not found in the first run WARFARES that we examined

27A*	1383027	27A-WAR15LW	BEARING HOUSING (REV O HAD WRONG SIZE DO NOT USE!)
------	---------	-------------	--

27A* 1446772 27A-WAR30LW BEARING HOUSING (REV 1 HAS CORRECT SIZE - USE THIS!)

BEARING AND WASHER CORRECTION

40	1383042	40-WAR15LW	BALL BEARING, SPOOL, OUTER, NON HANDLE SIDE (** wrong bearing listed in Penn's Rev U)
	1451534	40-WAR30LW	BALL BEARING, SPOOL, OUTER, NON HANDLE SIDE (** corrected by Penn Rev 1) USE THIS ONE

40A 1383043 40A-WAR15LW WASHER(** wrong part listed in Penn's Rev 0)
1446773 40-WAR30LW WASHER (** corrected by Penn Rev 1) -- USE THIS ONE --

SPOOL BEARING AND PIN

55	1451533	55-WAR15LW	BEA	ARING	(AT	TACH	HED T	O SPOOI	L SHAFT)

NOTE 1191256 20-1000AF BEARING (ATT<mark>ACHED</mark> TO SPOOL SHAFT) * old key#20A (CAN BE USED IF THE 55 PART IS NOT AVAILABLE)

We originally used 20-1000AF as the spool bearing, which wasn't on the Penn RevO schematic, but we now have the correct # 55-WAR15LW

29A 1451532 29A-WAR15LW PIN TO HOLD IN SPOOL BEARING

MYSTIC REEL PARTS REVISION!

NOTE:

Many of www.mysticparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.

MRP Ver 022822 (based on Penn's Rev. 1 2-16-2017)

^{* 62 -} HAD TWO KINDS 7 COIL AND 5 COIL, SEEMED RANDOM

^{*40}B rev.0 of schematic said felt, but what was in the reels were plastic